



EZ Connect Application Settings

- Pair the EZ Pen with applicable annotation software.
- Launch annotation software with a click of the EZ Pen 4 colour clicker.
- Set the default website for the Internet button.
- Set the default folder location for the Folder button.
- Customize update options.

Driver Installation

The EZ Pen & EZ Buttons require EZ Connect application software to work. If you do not have this, please follow the link below.


www.D3World.net/downloads

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Product Features

- RF - 2.4GHz ISM Band (2.405 ~ 2.470)
- 8 buttons (Touch sensor)
- EZ Pen Battery Charging (4.2V 50mA)
- Charging Status LED
- Power Input - 5V (USB)
- Dimensions (W x H x D mm) 39 x 301 x 72



- RF - 2.4GHz ISM Band (2.405 ~ 2.470)
- 4 Colour Clicker
- Scroll Wheel & Mode Button
- LED Battery Indication - 3 Types (Blue, Magenta, Red)
- Battery - Li-ion 3.7V 100mAh
- Dimensions - 178mm x 22Ø



EZ CONNECT™
T E C H N O L O G Y

EZ Pen & EZ Button